

Drop Wire

40" Horizontal clearance from Power
18" Vertical at house attachment 12" to 24"

S Knob/screw	0-30°		1 drop
Angle Screw	30°-60°		1 drop
Twisted Bracket	60°-90°	road xing	2 drops 1 multi
L Bracket	any	road xing	2 drops 1 multi
Rams horn (masonry)	any	road xing	2 drops 1 multi

J Hooks
4" above strand to house
6" below strand Pole to Pole or midspan
6 drops no more than 2 same direction
1 multi per J Hook
another J Hook 2" up 1" aside
Span clamp 2 drops or 1 multi